# *Voice Coding, PCM Voice, Voice Quality, E-model*

- ✓ **PCM ~ Pulse Code Modulation**
  - › **Sampling**
  - › **Quantizing**
    - • **Linear**
    - • **Non-linear**
  - › **Quantizing error**
- ✓ **PCM frame structure**
- ✓ **Other Voice coding algorithms**
- ✓ **E-model, Voice quality measurements**
- ✓ **Requirements to signaling.**

Voice path is established and its quality is controlled by signaling

Requirements for the Voice path and the Switching Fabric

✓ **In CSN the Switching Fabric must understand the bits, the timeslots and the frames in the same way as the transmission systems that carry the bits**
  › **The Fabric and the transmission systems must be synchronized**

✓ **Voice must be coded efficiently** (what is efficient changes over time)

✓ **An exchange must supervise voice connections:**
  › **calls shall/should not be offered to faulty connections**
  › **calls must sometimes be cleared from faulty connections**
  › **detected faulty connections must be reported to the far end if possible**

✓ **In a packet network voice path supervision is delegated to terminals**
  › **Many routers are unable to detect link failures with hardware. Instead the routing protocol hello messages are used → slow error detection and packet loss.**


Sampling

✓ **Nyquist theorem**
  › **If an analogue signal with limited spectrum is sampled regularly with a frequency of at least twice as high as the highest frequency component, the samples carry all the information in the original signal. The original signal can be reconstructed using a low pass filter.**

Key assumptions in Circuit telephony: PSTN, ISDN

✓ **In voice transmission, the spectrum carried is specified to be 300 - 3400 Hz, resulting in a minimum sampling rate of 6,8 kHz.**

✓ **In practice, since the width of the transmission channel in an analogue system is 4kHz, in a digital system a sampling rate of 8 kHz (8000 samples/s) is used.**

Wideband codecs, such as WB-AMR and WB-GIPS use a sampling rate of 16 kHz

Digital voice transmission

✓ **The voice path includes a microphone, A/D-converter, D/A-converter and a loudspeaker.**

✓ **In practice, the analogue signal needs to be filtered before the conversion**

microphone   switch   Transmission path   Low pass filter

| A/D coding | - - - - - - | D/A decoding | ≈

receiver

Sampling
capacitor

Pulse Code Modulation - PCM

✓ **In PCM, analogue voice is digitized and thus it can be carried by digital transmission systems and switched in digital switching fabrics.**

✓ **PCM was invented in 1937 but the first real implementations became possible only using transistor technology during 1960's. This is also one of the origins of Nokia Electronics (1968) and Nokia Networks.**

✓ **PCM conversion has four steps:**
  › **filtering**
  › **sampling**
 › **quantizing**
  › **coding**

Sampling of the analogue signal

- ✓ **Sampling of the analogue signal is done with a frequency of 8 kHz, I.e. with an inter-sample interval of 125 μs.**
- ✓ **The result is a PAM –signal: 8000 samples/second evenly spaced in time**

125μs: distance between samples

Pulse Amplitude Modulation PAM

- ✓ **Sampling produces a time discrete PAM signal reflecting the amplitude of the analogue signal.**
- ✓ **PAM-signal is quantized producing PCM-code.**

Quantizing = replacement of real value by the closest integer.

Quantizing results in approximation of the samples

✓ **Real valued amplitude figures are replaced by discrete integer values.**

✓ **Quantizing should result in values that appear in the signal with equal probability.**

Quantizing distortion

✓ **Quantizing produces distortion, that is called quantizing distortion.**

✓ **Quantizing distortion is made by the replacement of real values by their integer approximates and at maximum can reach ½ quantizing interval.**

✓ **In linear quantizing the signal to distortion ratio is**

S/D=6n+1,8 dB   n=word length

12

11   ↕ **Quantizing error**

10

9

Linear vs. non-linear

- ✓ **The result of quantizing should use signal values with equal probability.**
- ✓ **This results in minimization of distortion, because a larger number of discrete signal values falls into the most typical analogue signal value area.**
- ✓ **The effect of the quantizing error on voice quality is averaged over time by the ear.**
- ✓ **In a voice signal, small analogue values appear with higher probability than larger values.**

--> non-linear quantizing

Non-linearity

- ✓ **Non-linear conversion can be implemented in two ways:**
  - › **using non-linear quantizing**
  - › **using compression before linear quatizing is applied**
- ✓ **Non-linear quantizing can be implemented e.g. using a network of resistors, compression requires a non-linear amplifier.**
- ✓ **Irrespective of the method of implementation, the non-linear quantizing follows a conversion function giving the mapping of analogue signal values to integers.**
  - › **In Europe (ETSI) A-function**
  - › **In USA (ANSI) µ-function**

PCM-coding and quantizing

✓ **Accoding to ETSI specification, voice coding uses 8 bits per sample.**
  › **bit-1 gives the polarity of the signal**
  › **bits 2-4 give the segment of the non-linear quantizing**
  › **bits 5-8 give the value of the discrete signal inside the segment**
✓ **Non-linearity follows the so called A -law**

$$\left(\frac{A|x|}{1+\ln(A)}\right), 0 \leq |x| \leq \frac{1}{A}$$

$$\left(\frac{1+\ln|Ax|}{1+\ln(A)}\right), \frac{1}{A} \leq |x| \leq 1$$

The value of A is 87,6.

Quantizing according to the A-law

Quantizing inside a Segment

✓ **In a segment quantizing is linear**

1 101 1111

1 101 0000

xxxx 1111

Linear vs non-linear quantizing

✓ **Linear and non-linear quantizing can be compared using the gain in signal resolution by non-linearity.**

✓ **Non-linear quantizing emphasizes small signal values, for which a gain in resolution of 24 dB is achieved.**

$$G_{dB}=20\log V_{in}/V_{comp}$$

PCM-hierarchy

✓ **PCM-hierarchy is created by overlapping time division multiplexed signal connections byte by byte (sample by sample). Bits become shorter.**

✓ **The basic speed in the hierarchy is the bitrate of a single voice channel**

$S=8000Hz* 8bit = 64kbit/s,$

✓ **in time in a 2Mbit/s PCM system, this looks like:**

0 1 2 3   31 0 1 2 3 4 5

0   62,5   125   time, μs

✓**The following voice channel groups are defined**
> ›**30 voice channels**
> ›**120 voice channels**
> ›**480 voice channels**
> ›**1920 voice channels**

PCM 30 (E1)

✓ **The most common information switching and transmission format in the telecommunication network is PCM 30.**

✓ **PCM 30 contains:**
> › **1 synchronization and management channel**
> › **1 signaling channel**
> › **30 voice channel**

✓ **A channel is a time slot in the PCM-frame (125μs), created by TD multiplexing.**

✓ **PCM 30 system carries 32 time slots, each 64kbit/s. This gives a total bit rate of 2048kbit/s.**

PCM 30 frame

✓ **PCM 30 -frame contains 32 time slots**

  › time slot 0 is dedicated for synchronization and management information

  › **Time slot 16 is assigned for signaling information (CAS)**

  › **Time slots 1-15 and 17-32 are voice or user information channels**

✓ **Even and odd frame structures differ**

  › **In even numbered frames time slot 0 carries the frame alignment signal (C0 01 10 11). C is the CRC-bit (cyclic redundancy check) for ensuring the frame alignment recovery in case someone is sending X0 01 10 11 on a user information channel – this addition was forced by ISDN which supports transparent 64kbit/s service for data transfer.**

  › **Time slot 0 in odd frames carries alarm information. To avoid wrong frame alignment, the second bit in tsl 0 is set to the constant value of 1.**

The use of PCM time slots in the Finnish CCS#7 network

Voice or user information channels   **2 - 31**

CCS#7 signaling channel 1

PCM-alarms, frame alignment   **0**

Nowadays, tsl 16 is used for voice!
On PCM:s that do not need to have a signaling channel,
Tsl-1 may be used for voice or left reserved for signaling
for simplicity.

Even numbered PCM 30 -frame

1 multi-frame = 16 frames = 2 ms

	K0	K1	K2	K3	K4	K5	K6	K7	K8	K9	K10	K11	K12	K13	K14	K15	

1 frame = 32 time slots (even frame)

T0	T1	T2	T3	T4	T5	T6	T7	T8	T9	T10	T11	T12	T13	T14	T15	T16	T17	T18	T19	T20	T21	T22	T23	T24	T25	T26	T27	T28	T29	T30	T31

KL — Voice channels 1 - 15 — MA — Voice channels 16 - 30

**Frame alignment time slot T0**

B1	B2	B3	B4	B5	B6	B7	B8
C	0	0	1	1	0	1	1

7 bits for alignment in even frames

CRC -bit

Signaling time slot T16

B1	B2	B3	B4	B5	B6	B7	B8
0	0	0	0	1	A	1	1

Multi-frame alignment in frame 0

Multi-frame alarm

Voice channel 26 time slot T27

B1	B2	B3	B4	B5	B6	B7	B8

Voice Sample amplitude value

polarity

Applies only to K0, other even numbered, look at the next slide

---

PCM-frame structure (odd frame)

1 multi-frame = 16 frames

	K0	K1	K2	K3	K4	K5	K6	K7	K8	K9	K10	K11	K12	K13	K14	K15	

1 frame = 32 time slots (odd frame)

T0	T1	T2	T3	T4	T5	T6	T7	T8	T9	T10	T11	T12	T13	T14	T15	T16	T17	T18	T19	T20	T21	T22	T23	T24	T25	T26	T27	T28	T29	T30	T31

KL — Voice channels 1 - 15 — MA — Voice channels 16 - 30

Frame alignment time slot T0

B1	B2	B3	B4	B5	B6	B7	B8
C	1	A	D	D	D	D	D

Data bits for mgt

CRC -bit

Far end alarm

Signaling time slot T16

B1	B2	B3	B4	B5	B6	B7	B8
a	b	c	d	a	b	c	d

Channel 1 signaling bits

Channel 16 signaling bits

A number of other voice coding algorithms exist, more are developed all the time.

- ✓ **PCM coding is called G.711 – a ITU-T standard**
- ✓ **Examples:**
  - › GSM EFR codec (enhanced full rate),
  - › AMR (Adaptive Multirate) is the new emerging cellular standard codec, has NB-AMR and WB-AMR variants – narrow band, wide band. Wide band means that Voice is first cut into 7kHz (not 4kHz) prior to sampling.
  - › G.7xx – many codecs for packet voice, many of them patented, patents require licensing – difficult to use widely.
- ✓ **Leads to a need to negotiate about codecs end-to-end! This is a requirement for signaling. In CS networks, a codec needs to be standardized globally. In PS networks, it is enough to agree on a small set and be able to agree on a common codec end to end for a call.**

Some codecs and their characteristics

Coding Standard	Algorithm	Sample Size (msec)	Rate Kbit/s	Mean Opinion Score	Year
G.711	PCM	0.125	64	4.10	1972
GSM 06.10	RPE-LTP	20.000	13	3.50	1987
G.726, G727	ADPCM	0.125	16, 24, 32, 40	3.85	1990
G.728	LDCELP	0.625	16	3.61	1992, 1994
IS-96	VSELP	20.000	8.5, 4, 2, 0.8		1993
G.729, G.729a	CS-ACELP	10.000	8	3.92, 3.70	1995
G.723.1	MPC-MLQ	10.200	6.3, 5.3	3.90	1995
PDC	PSI-CELP	40.000	3.45		1996
FS-1015	LPC	25.700		2.40	-
AMR-NB					
AMR-WB				>PCM	

Voice quality can be assessed by Mean Opinion Score or MOS -value

✓ **Take 20 people, organise a controlled experiment with recorded voice samples (both male and female voices), use several languages,**

  › **After listening the test subject marks his/her opinion: 5 –excellent quality, 1 – bad quality, Repeat for many samples, Calculate averages.**

  › **Make sure people do not get bored, so same people can not be used for long.**

  › **Results may depend on time, test conditions and the group of people**

  › **Method is also called Absolute Category Rating**

✓ **Alternatively a comparative method can be used – Poor or Worse (PoW), Good or Better (GoB)**

✓ **Cumbersome and expensive → objective measurements.**


Comparison of GSM and AMR codecs

All use 16 kbit/s full rate channel in this comparison!

E-model (G.107) produces the R-value for characterizing voice quality

✓ **R-value varies between 0….100. In practice below 50 is unacceptable quality. With narrow band coding (3.1 kHz band) the maximum R-value is 94.15**

R   User satisfaction   MOS

100
G.107 base → 94   Very satisfied
90   4,3
          Satisfied
80   4,0
          Some unsatisfied
70   3,6
          Many unsatisfied
60   3,1
          Almost all users unsatisfied
50   2,6
          Not recommended
                                        1,0

MOS scale is
5 – Excellent
4 – Good
3 – Fair
2 – Poor
1 – Bad

There are measurement devices that produce R –values!

R-value is an "objective" measure calculated based on voice impairements

Impairements include: packet loss(sample loss), echo, delay, noise, etc

Impairements are additive over a connection!

$$R = R_0 - I_s - I_d - I_e + A$$

R_0 – basic value reflecting signal to noice ratio
I_s – sending impairements
I_d – delay and echo impairements
I_e – handware (e.g. codec) impairements (G.113 has a list of values for different codecs
A – reflects positive conditions (mobility, satellite…)

$$MOS = 1 + 0.035R + R(R - 60)(100 - R)*7e-6$$

To eliminate echo on long connections, echo cancellers and echo suppressors are used – these need to be controlled by signaling

Delay example: distance from A to B is 20 000 km in Fiber:

$$\text{Delay} = \frac{20\ 000\ \text{km}}{200\ 000\ \text{km/s}} = 100\ \text{ms}$$

Satellite on the Geostationary orbit:

$$\text{Delay} = \frac{80\ 000\ \text{km}}{300\ 000\ \text{km/s}} = 266\ \text{ms}$$

Echo is produced at 4/2 wire conversion. Example is analogue subscriber interface. Also voice can leak from loadspeaker to microphone (speakerphone). When delay > 30 ms, echo needs to be cancelled.

Earth

Voice quality starts to degrade, when one way end-to-end delay > 150ms

R

MOS

Perceived subjective quality

PCM voice quality in ISDN network

150 ms

Delay

Quality can be measured e.g. based on the E-model or using MOS –measurements. MOS - Mean Opinion Score.

Voice transfer and signaling

- ✓ **Voice path set-up is controlled by signaling**
- ✓ **Voice quality is controlled by switching systems in circuit switched networks**
  - › **e.g. voice path testing prior to call set-up**
  - › **Signaling may carry information that "this is a voice call" and apply echo cancellers on long international connections.**
  - › **Echo cancelling must not be applied to data connections!**
  - › **Coders are globally standardized**
- ✓ **In Packet networks voice quality is an end-to-end matter – terminals are responsible**
  - › **Terminals may also negotiate which coder to use, the network does not need to know about that!**
- ✓ **Quality impairements are additive end to end! Better select such path that impairements are minimized.**
  - › **Transcoder Free Operation, Translation Free Operation etc...**