
Common Channel Signaling Nr 7 (CCS7)

CCS7 is a *message based*, *multi-layer network to network* signaling system designed for fully digital exchanges.

- ✓ Limitation of analogue signaling systems
- ✓ Basic definitions for CCS7
- ✓ CCS7 Requirements
- ✓ Functional Structure
- ✓ MTP and SCCP
- ✓ User Parts
- ✓ Strengths and weaknesses



Limitations of Analogue signaling

- > Limited set of signals --> limited set of services
- > Always bound to a voice path --> architectural limitation.
- Difficult to change anything in an established call because registers have been released and voice channel is reserved for voice.
- > Slow --> uneconomical use of network resources.
- MF requires special equipment Only recently general purpose DSPs have become powerful and cost efficient enough.
- > HDLC on silicon --> processing hdlc frames and messages is simple and efficient on any computer.


© Rka -S-2006 Signaling Protocols 5 - 3

Does CCS7 remove all limitations?

- ✓ Digital messages --> unlimited signal set: e.g. 2¹⁰⁰ different signals can easily be devised.
- ✓ Common signaling channel for many voice channels (out-of-band) --> signaling is not, in principle, bound to calls nor voice/information channels. Signaling can continue during the call.
- ✓ Message round-trip delay on a 64kbit/s channel is ≈ 50 ms. --> post dialling delay (delay from the dialing of the last digit until the ringing tone) approaches zero.
- ✓ Makes use of HDLC -protocol framing and principles.

Basis of CCS7 is the signaling network - a special kind of data network.

STP - signaling transfer point




Examle: In Finnish CCS7 no specialized STP -nodes were originally deployed. STP functions were integrated in exchanges. E.g in USA, specialized STP-nodes are commonplace. A use case of STPs is for concentrating IN signaling traffic towards IN nodes that provide Nationwide services.


© Rka -S-2006 Signaling Protocols 5 - 5

Key definitions for CCS7

Signaling Point is a logical entity, e.g. in an exchange, there can be one or more SPs. In one CCS7 signaling network an exchange will, however, have only one Signaling Point Code.




Signaling connection can be either direct or indirect (through STP nodes)



CCS7 reliability is built by software

- Speed: post dial delay (until ringing tone) ≤ 2.2 s.
- MTP:
 - unavailability of signaling route set ≤ 10 min/annum
 - share of undetected faulty signaling messages: $\leq 10^{-10}$
 - loss probability of signaling messages $\leq 10^{-7}$
 - probability of reordering or replication of signaling messages ≤ 10⁻¹⁰
- Expected quality of of the underlying transmission network:
 - Long term bit error rate $\leq 10^{-6}$
 - Medium term bit error rate $\leq 10^{-4}$
- Using software means reliability is increased by several 10-folds!!

Why is it a good idea to require high availability performance from signaling?



- ✓ All parts of the above sequencial reliability model need to work for an operator to earn money on a voice call. The weakest link determines the availability perceived by the end user.
- ✓ By eliminating loss of revenue due signaling and call control failures, operators make good of the investment on the expensive transmission path for voice and recover the huge fixed cost that they must carry.

© Rka -S-2006 Signaling Protocols 5 - 9

In previous setting the total reliability is

$$\mathbf{R} = \mathbf{R}_1 \times \mathbf{R}_2 \times \mathbf{R}_3 \times \mathbf{R}_4$$


Example


$$R_1 = 0.999, R_2 = 0.998, R_3 = 0.997, R_4 = 0.92$$


$$R = 0.999 \times 0.998 \times 0.997 \times 0.92 = 0.914$$


The weakest link determines the total reliability

A term that is close to 1 has no impact.










Terms


- ✓ BSSAP Base Station Subsystem Application Part
 - > used for BSS to MSC signaling in GSM
 - > MSC Mobile Switching Center
 - > Handover support and location updates are important features of BSSAP
 - > BSSAP includes DTAP data transfer application part
- ✓ ISUP ISDN user part
- ✓ SCCP Signaling Connection Control Part
 - > used for call unrelated signaling
- ✓ TCAP Transaction Capabilities Application Part
 - > provides generic application services for transactions such as IN service logic requests and responses
- ✓ INAP Intelligent Network Application Part
 - > the protocol that exchanges (containing SSF service switching functions) use to access IN service logic in SCFs, Service Contorol Functions and SCFs use to access data in Service Data Functions (SDF)

© Rka -S-2006 Signaling Protocols 5 - 15

Key concepts in MTP are



- ✓ Signalling link one 64 kbit/s point-to-point channel
- ✓ Signalling link set (SLS) set of sig. links with the same endpoints
- ✓ Signalling Route a sequence of sign link sets between two SPs.
- ✓ Signalling Route set all sign. Routes connecting two SPs.



MTP - main functions are

- Switching functions: reconfiguration of the signaling network
- LEVEL 2: Signaling channel functions: LAPB / cmp. HDLC
 - frame alignment flags (delimiters) acc to HDLC principles
 - checksum, retransmission of message units, supervision of message ordering, acknowledgements, link fault detection and recovery


LEVEL 3:

- Load sharing among signaling links
- STP and distribution to User Parts
- Routing is based on 14-bit (ETSI) signaling point codes.
 - Management of signaling traffic:
 - link switchover messages are not lost!

5 - 18

- (Original) link restoration
- forced re-routing
- controlled re-routing

MTP has three message types




MSU - carries all payload of upper layers

LSSU - MTP level messaging between neighboring SPs

FISU - when there is nothing else to send! Originally made implementation difficult - short FISUs -> when there is no useful information to send the signaling terminal had the peak load!

© Rka -S-2006 Signaling Protocols 5 - 19

Message Signaling Unit structure is



F - Flag (delimiter -01111110)

BSN - Backward sequence number

BIB - Backward indicator bit

FSN - Forward sequence number

FIB - Forward indicator bit

LI - Length indicator

SIO - Service information octet

SIF - Service Information field

= payload

CK - Check bits


BSN and FSN have link local significance

© Rka -S-2006 Signaling Protocols

5 - 20

Service Information Octet (SIO) defines the target application

SIO




Network indicator: National NA0, 1 or International IN0, 1 -network.

A CCS7 network is not global. The global signaling network is formed by interconnecting CCS7 networks owned by different operators.

© Rka -S-2006 Signaling Protocols 5 - 21

MTP Route Label has three fields




SLS - Signalling link selection (for link load sharing)

DPC - destination point code OPC - originating point code

The shown lengths are acc to International (and Finnish) specification, in ANSI specs OPC/DPC lengths are 24 bits!


Load sharing has an impact on signal routing



To preserve the order of signals, higher levels set the SLS value so that the route remains the same e.g. for all signal messages of a single

© Rka -S-2006 **Signaling Protocols** 5 - 23

Flow of signaling messages in case of International GSM location update



INO - used International CCS7 network


Signaling Point Codes are unique only in one signaling network!! In this example, SCCP would be used to carry MAP/TCAP messages

SCCP - Signalling Connection Control Part expands MTP networking services

- ✓ MTP uses 14-bit signaling point codes as addresses - this is not enough in the global network.
- ✓ No relationship to voice channels: SCCP can be used to signal events that are unrelated to calls (such as location updates in mobile networks).
- ✓ SCCP brings Global Title an extension to the addressing mechanisms provided by the MTP.

© Rka -S-2006 Signaling Protocols 5 - 25

Fourth level (here ISUP) is needed, when MTP-signal message routing is not enough



- Messages/calls through an international signaling point
- · Calls across an operator boundary
- Intelligent Network calls
- In general, when the OP does not know the location of the called party


4th level = SCCP or a User Part.

If signaling is call related – UP, if not SCCP. If UP usually no SCCP is needed.

© Rka -S-2006

Signaling Protocols

5 - 26



Global Title in SCCP supports global messaging over the CCS7 network

Calling and called party in SCCP 6 5 4 Natio RI -PCode SSN GT Routing nal Indicator ind ind use indicator Signaling Point Code Sub System Number (SSN) Global title translation type Numbering plan Coding method Address type Address information

SSN (cmp. Port Numbers in TCP/IP) 1 - SCCP management 2 - TUP 3 - ISUP 4 - OMAP - Operation and Maintenance AP 5 - MAP - Mobile AP 6 - MAP/HLR 7 - MAP/VLR 8 - MAP/MSC 9 - MAP/EIR - Equipment Id reg 10 - MAP/AuC 11 - ISUP/SS ISUP supplementary services 12...247, 249...252 reserved 248 - MUP (NMT Mobile UP 253 - OMC - Operation and **Maintenance Center** 254 - BSSAP - BSS Applic. part

Address Information in GT of SCCP can be a telephone number or a subscriber identity

E.212: IMSI: MCC MNC MSIN E.g. 244 05 87654321

E.164: MISDN: CC NDC SN E.g. 358 40 540 3127

E.214: Hybrid: CC NDC MSIN E.g. 358 40 87654321

IMSI - International Mobile Subscriber Identity

MCC - Mobile Country Code


MNC - Mobile Network Code

MSIN - Mobile Subscriber Identity Number

CC - Country Code

NDC - National Destination Code

SN - Subscriber Number



SCCP use cases

- ✓ GT addresses are allocated for Network elements such as MSC or HLR. When e.g. a user's MSISDN appears in a call releted ISUP message it is carried in a Called_party or some such information element not Global Title.
 - Number portability will not cause difficulties for GT addressing since GT numbers are not ported from network to network like user allocated MSISDN numbers can be.
- ✓ Use cases for SCCP are not directly call related:
 - MAP: location update, HLR to VLR subscriber profile updates, routing information requests from GMSC to HLR etc
 - > INAP: call service logic requests from an exchange (Service Switching Function) to an IN node (SCF Service Control Function). During such signaling voice channel control stays in the SSF. The SCF may be remote, even in a different network cmp to SSF.
 - > CAP: similar to INAP. SCF resides in most cases in the home network.
- ✓ If a call requires global addressing, then globally unique E.164 telephone numbers are used in ISUP, no SCCP is in practise needed.

© Rka -S-2006 Signaling Protocols 5 - 31

User Parts (Ups)

For call setup, release and supplementary services!

✓ TUP - Telephony User Part - oldest and simples

- > National variants!
- > Messages bound to voice channels with Circuit Identification Code (CIC) in every message

✓ ISUP - ISDN User Part

supports wire-line ISDN calls
 speech, 64kbit/s, multi-channel: 128, 384, 1536, 1920 kbit/s services

✓ MAP - Mobile Application part -

- \rightarrow used in GSM e.g. for HLR MSC communication
- > provides mobility management

CCS7

Strengths

and weaknesses

- ✓ Large nrof of signals
- message based -> native for digital exchanges and computers
- out-of-band --> signaling can continue for the duration of the call and even independent of any calls
- ✓ Reliable
- MAP provides mobility management

- √ Complicated to implement
- ✓ Heritage of a closed market
- ✓ Service dependent new services require new fields into signaling messages and thus software upgrades in exchanges
- Requires new features to be secure in a competitive multioperator environment
- * At its best overlying a rather unreliable base network, reliability has been enhanced by software functions.

© Rka – S-2006 Signaling Protocols 5 - 33

The current CCS7 environment may have potentially hostile third parties | Service provider Y | Service provider X | Service provider X | Service provider Y | Service provider Y